

---

## Troubleshooting

|  |      |
|--|------|
| 9.1 Alarm Displays .....   | 9-2  |
| 9.1.1 List of Alarms .....   | 9-2  |
| 9.1.2 Troubleshooting of Alarms .....  | 9-7  |
| 9.2 Warning Displays .....   | 9-23 |
| 9.2.1 List of Warnings .....   | 9-23 |
| 9.2.2 Troubleshooting of Warnings .....  | 9-24 |
| 9.3 Monitoring Communication Data on Occurrence of an Alarm<br>or Warning .....              | 9-28 |
| 9.4 Troubleshooting Malfunction Based on Operation<br>and Conditions of the Servomotor ..... | 9-29 |

## 9.1 Alarm Displays

The following sections describe troubleshooting in response to alarm displays.

The alarm name, alarm meaning, alarm stopping method, and alarm reset capability are listed in order of the alarm numbers in *9.1.1 List of Alarms*.

The causes of alarms and troubleshooting methods are provided in *9.1.2 Troubleshooting of Alarms*.

### 9.1.1 List of Alarms

This section provides list of alarms.

#### ■ Servomotor Stopping Method

If an alarm occurs, the servomotor can be stopped by doing either of the following operations.

Gr.1: The servomotor is stopped according to the setting in Pn001.0 if an alarm occurs. Pn001.0 is factory-set to stop the servomotor by applying the DB.

Gr.2: The servomotor is stopped according to the setting in Pn00B.1 if an alarm occurs. Pn00B.1 is factory-set to stop the servomotor by setting the speed reference to "0." The servomotor under torque control will always use the Gr.1 method to stop. By setting Pn00B.1 to 1, the servomotor stops using the same method as Gr.1. When coordinating a number of servomotors, use this stopping method to prevent machine damage that may result due to differences in the stop method.

#### ■ Alarm Reset

Available: Removing the cause of alarm and then executing the alarm reset can clear the alarm.

N/A: Executing the alarm reset cannot clear the alarm.

| Alarm Number | Alarm Name  | Meaning   | Servo-motor Stopping Method | Alarm Reset |
|--------------|---|---|-----------------------------|-------------|
| A.020        | Parameter Checksum Error 1                                    | The data of the parameter in the SERVOPACK is incorrect.  | Gr.1                        | N/A         |
| A.021        | Parameter Format Error 1                                      | The data of the parameter in the SERVOPACK is incorrect.  | Gr.1                        | N/A         |
| A.022        | System Checksum Error 1                                       | The data of the parameter in the SERVOPACK is incorrect.  | Gr.1                        | N/A         |
| A.030        | Main Circuit Detector Error                                   | Detection data for main circuit is incorrect.   | Gr.1                        | Available   |
| A.040        | Parameter Setting Error 1                                     | The parameter setting is outside the setting range.   | Gr.1                        | N/A         |
| A.041        | Encoder Output Pulse Setting Error                            | The encoder output pulse (Pn212) is outside the setting range or does not satisfy the setting conditions.                   | Gr.1                        | N/A         |
| A.042        | Parameter Combination Error                                   | Combination of some parameters exceeds the setting range.   | Gr.1                        | N/A         |
| A.044        | Semi-closed/Fully-closed Loop Control Parameter Setting Error | The settings of the option module and Pn00B.3, Pn002.3 do not match.  | Gr.1                        | N/A         |
| A.04A        | Parameter Setting Error 2                                     | Bank member/bank data setting is incorrect.   | Gr.1                        | N/A         |
| A.050        | Combination Error   | The SERVOPACK and the servomotor capacities do not match each other.  | Gr.1                        | Available   |
| A.051        | Unsupported Device Alarm                                      | The device unsupported was connected.   | Gr.1                        | N/A         |
| A.0b0        | Cancelled Servo ON Command Alarm                              | The servo ON command (SV_ON) was sent from the host controller after executing a utility function that turns ON servomotor. | Gr.1                        | Available   |
| A.100        | Overcurrent or Heat Sink Overheated                           | An overcurrent flowed through the IGBT or the heat sink of the SERVOPACK was overheated.                                    | Gr.1                        | N/A         |

(cont'd)

| Alarm Number                 | Alarm Name                               | Meaning   | Servo-motor Stopping Method | Alarm Reset |
|------------------------------|--|---|-----------------------------|-------------|
| <b>A.300</b>                 | Regeneration Error                       | Regenerative circuit or regenerative resistor is faulty.  | Gr.1                        | Available   |
| <b>A.320</b>                 | Regenerative Overload                    | Regenerative energy exceeds regenerative resistor capacity.   | Gr.2                        | Available   |
| <b>A.330</b>                 | Main Circuit Power Supply Wiring Error   | <ul style="list-style-type: none"> <li>Setting of AC input/DC input is incorrect.</li> <li>Power supply wiring is incorrect.</li> </ul> | Gr.1                        | Available   |
| <b>A.400</b>                 | Overvoltage                              | Main circuit DC voltage is excessively high.  | Gr.1                        | Available   |
| <b>A.410</b>                 | Undervoltage                             | Main circuit DC voltage is excessively low.   | Gr.2                        | Available   |
| <b>A.450</b>                 | Main-Circuit Capacitor Overvoltage       | The capacitor of the main circuit has deteriorated or is faulty.  | Gr.1                        | N/A         |
| <b>A.510</b>                 | Overspeed                                | The servomotor speed is above the maximum rotational speed.   | Gr.1                        | Available   |
| <b>A.511</b>                 | Overspeed of Encoder Output Pulse Rate   | The pulse output speed upper limit of the set encoder output pulse (Pn212) is exceeded.   | Gr.1                        | Available   |
| <b>A.520</b>                 | Vibration Alarm                          | Incorrect vibration at the motor speed was detected.  | Gr.1                        | Available   |
| <b>A.521</b>                 | Autotuning Alarm                         | Vibration was detected while performing tuning-less function.   | Gr.1                        | Available   |
| <b>A.710</b>                 | Overload: High Load                      | The servomotor was operating for several seconds to several tens of seconds under a torque largely exceeding ratings.                   | Gr.2                        | Available   |
| <b>A.720</b>                 | Overload: Low Load                       | The servomotor was operating continuously under a torque exceeding ratings.   | Gr.1                        | Available   |
| <b>A.730</b><br><b>A.731</b> | Dynamic Brake Overload                   | When the dynamic brake was applied, rotational energy exceeded the capacity of dynamic brake resistor.                                  | Gr.1                        | Available   |
| <b>A.740</b>                 | Overload of Surge Current Limit Resistor | The main circuit power was frequently turned ON and OFF.  | Gr.1                        | Available   |
| <b>A.7A0</b>                 | Heat Sink Overheated                     | The heat sink of the SERVOPACK exceeded 100°C.  | Gr.2                        | Available   |
| <b>A.7AB</b>                 | Built-in Fan in SERVOPACK Stopped        | The fan inside the SERVOPACK stopped.   | Gr.1                        | Available   |
| <b>A.810</b>                 | Encoder Backup Error                     | The power supplies to the encoder all failed and position data was lost.  | Gr.1                        | N/A         |
| <b>A.820</b>                 | Encoder Checksum Error                   | The checksum results of encoder memory is incorrect.  | Gr.1                        | N/A         |
| <b>A.830</b>                 | Absolute Encoder Battery Error           | The battery voltage was lower than the specified value after the control power supply was turned ON.                                    | Gr.1                        | Available   |
| <b>A.840</b>                 | Encoder Data Error                       | Data in the encoder is incorrect.   | Gr.1                        | N/A         |
| <b>A.850</b>                 | Encoder Overspeed                        | The encoder was rotating at high speed when the power was turned ON.  | Gr.1                        | N/A         |
| <b>A.860</b>                 | Encoder Overheated                       | The internal temperature of encoder is too high.  | Gr.1                        | N/A         |
| <b>A.8A0</b>                 | External Encoder Error                   | External encoder is faulty.   | Gr.1                        | Available   |
| <b>A.8A1</b>                 | External Encoder Error of Module         | Serial converter unit is faulty.  | Gr.1                        | Available   |
| <b>A.8A2</b>                 | External Encoder Error of Sensor         | External encoder is faulty.   | Gr.1                        | Available   |
| <b>A.8A3</b>                 | External Encoder Error of Position       | The position data of external encoder is faulty.  | Gr.1                        | Available   |
| <b>A.8A5</b>                 | External Encoder Overspeed               | The overspeed from the external encoder occurred.   | Gr.1                        | Available   |
| <b>A.8A6</b>                 | External Encoder Overheated              | The overheat from the external encoder occurred.  | Gr.1                        | Available   |

(cont'd)

| Alarm Number       | Alarm Name   | Meaning  | Servo-motor Stopping Method | Alarm Reset |
|--------------------|--|--|-----------------------------|-------------|
| <b>A.A□□</b><br>*1 | SERVOPACK: Command Option Module Alarms                        | —  | —                           | —           |
| <b>A.b31</b>       | Current Detection Error 1                                      | The current detection circuit for phase U is faulty.   | Gr.1                        | N/A         |
| <b>A.b32</b>       | Current Detection Error 2                                      | The current detection circuit for phase V is faulty.   | Gr.1                        | N/A         |
| <b>A.b33</b>       | Current Detection Error 3                                      | The detection circuit for the current is faulty.   | Gr.1                        | N/A         |
| <b>A.b6A</b>       | MECHATROLINK Communications ASIC Error 1                       | ASIC error occurred in the MECHATROLINK communications.  | Gr.1                        | N/A         |
| <b>A.b6b</b>       | MECHATROLINK Communications ASIC Error 2                       | ASIC error occurred in the MECHATROLINK communications.  | Gr.2                        | N/A         |
| <b>A.bF0</b>       | System Alarm 0   | "Internal program error 0" of the SERVOPACK occurred.  | Gr.1                        | N/A         |
| <b>A.bF1</b>       | System Alarm 1   | "Internal program error 1" of the SERVOPACK occurred.  | Gr.1                        | N/A         |
| <b>A.bF2</b>       | System Alarm 2   | "Internal program error 2" of the SERVOPACK occurred.  | Gr.1                        | N/A         |
| <b>A.bF3</b>       | System Alarm 3   | "Internal program error 3" of the SERVOPACK occurred.  | Gr.1                        | N/A         |
| <b>A.bF4</b>       | System Alarm 4   | "Internal program error 4" of the SERVOPACK occurred.  | Gr.1                        | N/A         |
| <b>A.C10</b>       | Servo Overrun Detected   | The servomotor ran out of control.   | Gr.1                        | Available   |
| <b>A.C80</b>       | Absolute Encoder Clear Error and Multiturn Limit Setting Error | The multiturn for the absolute encoder was not properly cleared or set.  | Gr.1                        | N/A         |
| <b>A.C90</b>       | Encoder Communications Error                                   | Communications between the SERVOPACK and the encoder is not possible.  | Gr.1                        | N/A         |
| <b>A.C91</b>       | Encoder Communications Position Data Error                     | An encoder position data calculation error occurred.   | Gr.1                        | N/A         |
| <b>A.C92</b>       | Encoder Communications Timer Error                             | An error occurs in the communications timer between the encoder and the SERVOPACK.   | Gr.1                        | N/A         |
| <b>A.CA0</b>       | Encoder Parameter Error  | Encoder parameters are faulty.   | Gr.1                        | N/A         |
| <b>A.Cb0</b>       | Encoder Echoback Error   | Contents of communications with encoder are incorrect.   | Gr.1                        | N/A         |
| <b>A.CC0</b>       | Multiturn Limit Disagreement                                   | Different multiturn limits have been set in the encoder and the SERVOPACK.   | Gr.1                        | N/A         |
| <b>A.CF1</b>       | Feedback Option Module Communications Error (Reception error)  | Reception from the Feedback Option Module is faulty.   | Gr.1                        | N/A         |
| <b>A.CF2</b>       | Feedback Option Module Communications Error (Timer stop)       | Timer for communications with the Feedback Option Module is faulty.  | Gr.1                        | N/A         |
| <b>A.d00</b>       | Position Error Overflow  | Position error exceeded the value of excessive position error alarm level (Pn520) when the servomotor power is ON.                                       | Gr.1                        | Available   |
| <b>A.d01</b>       | Position Error Overflow Alarm at Servo ON                      | This alarm occurs if the servomotor power is turned ON when the position error is greater than the set value of Pn526 while the servomotor power is OFF. | Gr.1                        | Available   |

\*1. These alarms occur in SERVOPACKs with command option modules.  
For details, refer to the manual for the command option module that is connected.

(cont'd)

| Alarm Number               | Alarm Name   | Meaning  | Servo-motor Stopping Method | Alarm Reset |
|----------------------------|--|--|-----------------------------|-------------|
| <b>A.d02</b>               | Position Error Overflow Alarm by Speed Limit at Servo ON               | When the position errors remain in the error counter, Pn529 limits the speed if the servomotor power is turned ON. If Pn529 limits the speed in such a state, this alarm occurs when position references are input and the number of position errors exceeds the value set for the excessive position error alarm level (Pn520). | Gr.2                        | Available   |
| <b>A.d10</b>               | Motor-load Position Error Overflow                                     | During fully-closed loop control, the position error between motor and load is excessive.  | Gr.2                        | Available   |
| <b>A.E02</b>               | MECHATROLINK Internal Synchronization Error 1                          | Synchronization error during MECHATROLINK communications with the SERVOPACK.   | Gr.1                        | Available   |
| <b>A.E40</b>               | MECHATROLINK Transmission Cycle Setting Error                          | The setting of the MECHATROLINK transmission cycle is out of the allowable range.  | Gr.2                        | Available   |
| <b>A.E50</b>               | MECHATROLINK Synchronization Error                                     | A synchronization error occurs during MECHATROLINK communications.   | Gr.2                        | Available   |
| <b>A.E51</b>               | MECHATROLINK Synchronization Failed                                    | A synchronization failure occurs in MECHATROLINK communications.   | Gr.2                        | Available   |
| <b>A.E60</b>               | MECHATROLINK Communications Error (Reception error)                    | A communications error occurs continuously during MECHATROLINK communications.   | Gr.2                        | Available   |
| <b>A.E61</b>               | MECHATROLINK Transmission Cycle Error (Synchronization interval error) | The transmission cycle fluctuates during MECHATROLINK communications.  | Gr.2                        | Available   |
| <b>A.E71</b>               | Safety Option Module Detection Failure                                 | Detection of the safety option module failed.  | Gr.1                        | N/A         |
| <b>A.E72</b>               | Feedback Option Module Detection Failure                               | Detection of the Feedback Option Module failed.  | Gr.1                        | N/A         |
| <b>A.E74</b>               | Unsupported Safety Option Module                                       | An unsupported safety option module was connected.   | Gr.1                        | N/A         |
| <b>A.E75</b>               | Unsupported Feedback Option Module                                     | An unsupported feedback option module was connected.   | Gr.1                        | N/A         |
| <b>A.E81</b> <sup>*2</sup> | SERVOPACK: Safety Module Alarm   | –  | –                           | –           |
| <b>A.EA2</b>               | DRV Alarm 2 (SERVOPACK WDC error)                                      | A SERVOPACK DRV alarm 0 occurs.  | Gr.2                        | Available   |
| <b>A.Eb1</b>               | Safety Function Signal Input Timing Error                              | The safety function signal input timing is faulty.   | Gr.1                        | N/A         |
| <b>A.Eb□</b> <sup>*2</sup> | SERVOPACK: Safety Module Alarms  | –  | –                           | –           |
| <b>A.EC□</b> <sup>*2</sup> | SERVOPACK: Safety Module Alarms  | –  | –                           | –           |
| <b>A.Ed1</b>               | Command Execution Timeout  | A timeout error occurred when using a MECHATROLINK command.  | Gr.2                        | Available   |
| <b>A.F10</b>               | Main Circuit Cable Open Phase  | With the main power supply ON, voltage was low for more than 1 second in phase R, S, or T.   | Gr.2                        | Available   |
| <b>FL-1</b> <sup>*3</sup>  | System Alarm   | Internal program error occurred in the SERVOPACK   | –                           | N/A         |
| <b>FL-2</b> <sup>*3</sup>  |  |  | –                           | N/A         |

\*2. These alarms occur in SERVOPACKs with safety modules.

For details, refer to *Σ-V Series User's Manual, Safety Module* (No.: SIEP C720829 06).

\*3. These alarms are not stored in the alarm history and are displayed only in the panel display.

(cont'd)

| Alarm Number | Alarm Name                            | Meaning  | Servo-motor Stopping Method | Alarm Reset |
|--------------|---------------------------------------|--|-----------------------------|-------------|
| <b>CPF00</b> | Digital Operator Transmission Error 1 | Digital operator (JUSP-OP05A-1-E) fails to communicate with the SERVOPACK (e.g., CPU error). | –                           | N/A         |
| <b>CPF01</b> | Digital Operator Transmission Error 2 |  | –                           | N/A         |
| <b>A.--</b>  | Not an error                          | Normal operation status  | –                           | –           |

## 9.1.2 Troubleshooting of Alarms

If an error occurs in servo drives, an alarm display such as A.□□□ and CPF□□ will appear on the panel display.

Refer to the following table to identify the cause of an alarm and the action to be taken.

Contact your Yaskawa representative if the problem cannot be solved by the described corrective action.

| Alarm Number:<br>Alarm Name<br>(Alarm Description)   | Cause  | Investigative Actions   | Corrective Actions  |
|--|--|---|---|
| A.020:<br>Parameter Checksum<br>Error 1<br>(The parameter data in<br>the SERVOPACK is<br>incorrect.) | The power supply voltage suddenly dropped.   | Measure the power supply voltage.   | Set the power supply voltage within the specified range, and set Fn005 to initialize the parameter.                                   |
|  | The power supply went OFF while changing a parameter setting.  | Check the circumstances when the power supply went OFF.   | Set Fn005 to initialize the parameter and then set the parameter again.   |
|  | The number of times that parameters were written exceeded the limit.                                   | Check to see if the parameters were frequently changed through the host controller.                           | The SERVOPACK may be faulty. Replace the SERVOPACK. Reconsider the method of writing parameters.                                      |
|  | Malfunction caused by noise from the AC power supply or grounding line, static electricity noise, etc. | Turn the power supply ON and OFF several times. If the alarm still occurs, there may be noise interference.   | Take countermeasures against noise.   |
|  | Gas, water drops, or cutting oil entered the SERVOPACK and caused failure of the internal components.  | Check the installation conditions.  | The SERVOPACK may be faulty. Replace the SERVOPACK.   |
|  | A SERVOPACK fault occurred.  | Turn the power supply ON and OFF several times. If the alarm still occurs, the SERVOPACK may be faulty.       | The SERVOPACK may be faulty. Replace the SERVOPACK.   |
| A.021:<br>Parameter Format Error 1<br>(The parameter data in<br>the SERVOPACK is<br>incorrect.)      | The software version of SERVOPACK that caused the alarm is older than that of the written parameter.   | Check Fn012 to see if the set software version agrees with that of the SERVOPACK. If not, an alarm may occur. | Write the parameter of another SERVOPACK of the same model with the same software version. Then turn the power OFF and then ON again. |
|  | A SERVOPACK fault occurred.  | –   | The SERVOPACK may be faulty. Replace the SERVOPACK.   |
| A.022:<br>System Checksum Error 1<br>(The parameter data in<br>the SERVOPACK is<br>incorrect.)       | The power supply voltage suddenly dropped.   | Measure the power supply voltage.   | The SERVOPACK may be faulty. Replace the SERVOPACK.   |
|  | The power supply went OFF while setting a utility function.  | Check the circumstances when the power supply went OFF.   | The SERVOPACK may be faulty. Replace the SERVOPACK.   |
|  | A SERVOPACK fault occurred.  | Turn the power supply ON and OFF several times. If the alarm still occurs, the SERVOPACK may be faulty.       | The SERVOPACK may be faulty. Replace the SERVOPACK.   |
| A.030:<br>Main Circuit Detector<br>Error   | A SERVOPACK fault occurred.  | –   | The SERVOPACK may be faulty. Replace the SERVOPACK.   |
| A.040:<br>Parameter Setting Error 1<br>(The parameter setting<br>was out of the setting<br>range.)   | The SERVOPACK and servomotor capacities do not match each other.                                       | Check the combination of SERVOPACK and servomotor capacities.   | Select the proper combination of SERVOPACK and servomotor capacities.   |
|  | A SERVOPACK fault occurred.  | –   | The SERVOPACK may be faulty. Replace the SERVOPACK.   |
|  | The parameter setting is out of the setting range.   | Check the setting ranges of the parameters that have been changed.  | Set the parameter to a value within the setting range.  |
|  | The electronic gear ratio is out of the setting range.   | Check the electronic gear ratio. The ratio must satisfy:<br>$0.001 < (\text{Pn20E}/\text{Pn210}) < 4000$ .    | Set the electronic gear ratio in the range: $0.001 < (\text{Pn20E}/\text{Pn210}) < 4000$ .  |

(cont'd)

| Alarm Number:<br>Alarm Name<br>(Alarm Description)  | Cause  | Investigative Actions  | Corrective Actions   |
|---|--|--|--|
| A.041:<br>Encoder Output Pulse<br>Setting Error   | The encoder output pulse (Pn212) is out of the setting range and does not satisfy the setting conditions.  | Check the parameter Pn212.   | Set Pn212 to a correct value.  |
| A.042:*1<br>Parameter Combination Error   | The speed of program JOG operation (Fn004) is lower than the setting range after having changed the electronic gear ratio (Pn20E/Pn210) or the servomotor. | Check if the detection conditions*1 are satisfied.   | Decrease the setting of the electronic gear ratio (Pn20E/Pn210).                   |
|   | The speed of program JOG operation (Fn004) is lower than the setting range after having changed the setting of the program JOG movement speed (Pn533).     | Check if the detection conditions*1 are satisfied.   | Increase the setting of the program JOG movement speed (Pn533).                    |
|   | The moving speed of advanced autotuning is lower than the setting range after having changed the electronic gear ratio (Pn20E/Pn210) or the servomotor.    | Check if the detection conditions*1 are satisfied.   | Decrease the setting of the electronic gear ratio (Pn20E/Pn210).                   |
| A.044:<br>Semi-closed/Fully-closed Loop Control<br>Parameter Setting Error                  | The setting of the fully-closed module does not match with that of Pn002.3.  | Check the settings of Pn002.3.   | The setting of fully-closed module must be compatible with the setting of Pn002.3. |
| A.04A:<br>Parameter Setting Error 2   | For a 4-byte parameter bank, no registration in two consecutive bytes for two bank members.  | –  | Change the number of bytes for bank members to an appropriate value.               |
|   | The total amount of bank data exceeds 64. (Pn900 × Pn901 > 64)   | –  | Reduce the total amount of bank data to 64 or less.                                |
| A.050:<br>Combination Error<br>(The SERVOPACK and servomotor capacities do not correspond.) | The SERVOPACK and servomotor capacities do not match each other.   | Check the capacities to see if they satisfy the following condition:<br>$\frac{1}{4} \leq \frac{\text{Servomotor capacity}}{\text{SERVOPACK capacity}} \leq 4$ | Select the proper combination of SERVOPACK and servomotor capacities.              |
|   | An encoder fault occurred.   | Replace the servomotor and see if the alarm occurs again.  | Replace the servomotor (encoder).  |
|   | A SERVOPACK fault occurred.  | –  | The SERVOPACK may be faulty. Replace the SERVOPACK.                                |
| A.051:<br>Unsupported Device Alarm  | An unsupported serial converter unit, encoder, or external encoder is connected to the SERVOPACK.  | Check the product specifications, and select the correct model.  | Select the correct combination of units.   |
| A.0b0:<br>Cancelled Servo ON Command Alarm  | After executing the utility function to turn ON the power to the motor, the servo ON command (SV_ON) was sent from the host controller.                    | –  | Turn the SERVOPACK power supply OFF and then ON again or execute a software reset. |

\*1. Detection conditions

If one of the following conditions detected, an alarm occurs.

- $\text{Pn533} [\text{min}^{-1}] \times \frac{\text{Encoder resolution}}{6 \times 10^5} \leq \frac{\text{Pn20E}}{\text{Pn210}}$
- $\text{Max Motor Speed} [\text{min}^{-1}] \times \frac{\text{Encoder resolution}}{\text{About } 3.66 \times 10^{12}} \geq \frac{\text{Pn20E}}{\text{Pn210}}$



(cont'd)

| Alarm Number:<br>Alarm Name<br>(Alarm Description)  | Cause   | Investigative Actions  | Corrective Actions  |
|---|---|--|---|
| A.100:<br>Overcurrent or Heat<br>Sink Overheated<br>(An overcurrent flowed<br>through the IGBT or<br>heat sink of SERVO-<br>PACK overheated.) | Incorrect wiring or contact fault of main circuit cables.   | Check the wiring. Refer to <i>3.1 Main Circuit Wiring</i> .  | Correct the wiring.   |
|   | Short-circuit or ground fault of main circuit cables.   | Check for short-circuits across the servomotor terminal phases U, V, and W, or between the grounding and servomotor terminal phases U, V, or W. Refer to <i>3.1 Main Circuit Wiring</i> .            | The cable may be short-circuited. Replace the cable.  |
|   | Short-circuit or ground fault inside the servomotor.  | Check for short-circuits across the servomotor terminal phases U, V, and W, or between the grounding and servomotor terminal phases U, V, or W. Refer to <i>3.1 Main Circuit Wiring</i> .            | The servomotor may be faulty. Replace the servomotor.   |
|   | Short-circuit or ground fault inside the SERVOPACK.   | Check for short-circuits across the servomotor connection terminals U, V, and W on the SERVOPACK, or between the grounding and terminal U, V, or W. Refer to <i>3.1 Main Circuit Wiring</i> .        | The SERVOPACK may be faulty. Replace the SERVOPACK.   |
|   | Incorrect wiring or contact fault of the regenerative resistor.   | Check the wiring. Refer to <i>3.7 Connecting Regenerative Resistors</i> .  | Correct the wiring.   |
|   | The dynamic brake (DB: Emergency stop executed from the SERVOPACK) was frequently activated, or the DB overload alarm occurred. | Check the power consumed by DB resistance (Un00B) to see how many times the DB has been used. Or, check the alarm history display Fn000 to see if the DB overload alarm A.730 or A.731 was reported. | Change the SERVOPACK model, operating conditions, or the mechanism so that the DB does not need to be used so frequently.                 |
|   | The generated regenerative resistor value exceeded the SERVOPACK regenerative energy processing capacity.                       | Check the regenerative load ratio (Un00A) to see how many times the regenerative resistor has been used.   | Check the operating condition including overload, and reconsider the regenerative resistor value.   |
|   | The SERVOPACK regenerative resistance is too small.   | Check the regenerative load ratio (Un00A) to see how many times the regenerative resistor has been used.   | Change the regenerative resistance value to a value larger than the SERVOPACK minimum allowable resistance value.                         |
|   | A heavy load was applied while the servomotor was stopped or running at a low speed.  | Check to see if the operating conditions are outside servo drive specifications.   | Reduce the load applied to the servomotor or increase the operating speed.  |
|   | Malfunction caused by noise interference.   | Improve the wiring or installation environment, such as by reducing noise, and check to see if the alarm recurs.   | Take countermeasures for noise, such as correct wiring of the FG. Use an FG wire size equivalent to the SERVOPACK main circuit wire size. |
| A SERVOPACK fault occurred.   | –   | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.  |   |

(cont'd)

| Alarm Number:<br>Alarm Name<br>(Alarm Description) | Cause  | Investigative Actions  | Corrective Actions   |
|--|--|--|--|
| A.300:<br>Regeneration Error                       | <ul style="list-style-type: none"> <li>Regenerative resistor capacity (Pn600) is set to a value other than 0 for a SGD V-R70, -R90, -1R6, -2R1, or -2R8 SERVO-PACK, and an external regenerative resistor is not connected.</li> <li>An external regenerative resistor is not connected to the SGD V-470, SGD V-550, SGD V-590, SGD V-780, SGD V-210, SGD V-260, SGD V-280, or SGD V-370 SERVOPACK.</li> </ul> | Check the external regenerative resistor connection and the value of the Pn600.                            | Connect the external regenerative resistor, or set Pn600 to 0 if no regenerative resistor is required.   |
|  | The jumper between the power supply terminals B2 and B3 is removed for the SERVOPACKs other than the SERVOPACKs shown above.   | Confirm that a jumper is mounted between the power supply terminals B2 and B3.                             | Correctly mount a jumper.  |
|  | The external regenerative resistor is incorrectly wired, or is removed or disconnected.  | Check the external regenerative resistor connection.   | Correctly connect the external regenerative resistor.  |
|  | A SERVOPACK fault occurred.  | —  | While the main circuit power supply is OFF, turn the control power supply OFF and then ON again. If the alarm still occurs, the SERVO-PACK may be faulty. Replace the SERVOPACK.           |
| A.320:<br>Regenerative Overload                    | The power supply voltage exceeds the specified limit.  | Measure the power supply voltage.  | Set the power supply voltage within the specified range.   |
|  | Insufficient external regenerative resistance, regenerative resistor capacity, or SERVOPACK capacity.<br>Or, regenerative power has been continuously flowing back.  | Check the operating condition or the capacity using the capacity selection Software SigmaJunma-Size+, etc. | Change the regenerative resistance, regenerative resistor capacity, or SERVOPACK capacity. Reconsider the operating conditions using the capacity selection software SigmaJunmaSize+, etc. |
|  | Regenerative power continuously flowed back because negative load was continuously applied.  | Check the load applied to the servomotor during operation.   | Reconsider the system including servo, machine, and operating conditions.  |
|  | The setting of parameter Pn600 is smaller than the external regenerative resistor's capacity.  | Check the external regenerative resistor connection and the value of the Pn600.                            | Set the Pn600 to a correct value.  |
|  | The external regenerative resistance is too high.  | Check the regenerative resistance.   | Change the regenerative resistance to a correct value or use an external regenerative resistor of appropriate capacity.  |
|  | A SERVOPACK fault occurred.  | —  | The SERVOPACK may be faulty. Replace the SERVOPACK.  |

(cont'd)

| Alarm Number:<br>Alarm Name<br>(Alarm Description)   | Cause   | Investigative Actions   | Corrective Actions  |
|--|---|---|---|
| A.330:<br>Main Circuit Power<br>Supply Wiring Error<br>(Detected when the<br>power to the main circuit<br>is turned ON.) | The regenerative resistor disconnected when the SERVOPACK power supply voltage was high.  | Measure the resistance of the regenerative resistor using a measuring instrument.   | When using a regenerative resistor built in the SERVOPACK:<br>Replace the SERVOPACK.<br>When using an external regenerative resistor:<br>Replace the external regenerative resistor.                  |
|  | In the AC power input mode, DC power was supplied.  | Check the power supply to see if it is a DC power supply.   | Correct the settings to match the actual power supply specifications.   |
|  | In the DC power input mode, AC power was supplied.  | Check the power supply to see if it is an AC power supply.  | Correct the settings to match the actual power supply specifications.   |
|  | Regenerative resistor capacity (Pn600) is set to a value other than 0 for a SGDVR70, -R90, -1R6, -2R1, or -2R8 SERVOPACK, and an external regenerative resistor is not connected.   | Check the external regenerative resistor connection and the value of the Pn600.   | Connect the external regenerative resistor, or set Pn600 to 0 if no regenerative resistor is required.  |
|  | The jumper between the power supply terminals B2 and B3 is removed for the SERVOPACKs other than the SERVOPACKs shown above.  | Confirm that a jumper is mounted between the power supply terminals B2 and B3.  | Correctly mount a jumper.   |
|  | A SERVOPACK fault occurred.   | –   | The SERVOPACK may be faulty. Replace the SERVOPACK.   |
| A.400:<br>Overvoltage<br>(Detected in the SERVOPACK main circuit power supply section.)                                  | <ul style="list-style-type: none"> <li>For 100-VAC SERVOPACKs: The AC power supply voltage exceeded 145 V.</li> <li>For 200-VAC SERVOPACKs: The AC power supply voltage exceeded 290 V.</li> <li>For 400-VAC SERVOPACKs: The AC power supply voltage exceeded 580 V.</li> <li>For 200-VAC SERVOPACKs: with DC power supply input: The DC power supply voltage exceeded 410 V.</li> <li>For 400-VAC SERVOPACKs: The DC power supply voltage exceeded 820 V.</li> </ul> | Measure the power supply voltage.   | Set AC/DC power supply voltage within the specified range.  |
|  | The power supply is unstable, or was influenced by a lightning surge.   | Measure the power supply voltage.   | Improve the power supply conditions by installing a surge absorber, etc. Then, turn the power supply OFF and ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK. |
|  | Voltage for AC power supply was too high during acceleration or deceleration.   | Check the power supply voltage and the speed and torque during operation.   | Set AC power supply voltage within the specified range.   |
|  | The external regenerative resistance is too high for the actual operating conditions.   | Check the operating conditions and the regenerative resistance.   | Select a regenerative resistance value appropriate for the operating conditions and load.   |
|  | The moment of inertia ratio exceeded the allowable value.   | Confirm that the moment of inertia ratio is within the allowable range.   | Increase the deceleration time, or reduce the load.   |
| A SERVOPACK fault occurred.  | –   | Turn the control power OFF and then ON again while the main circuit power supply is OFF. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK. |   |

(cont'd)

| Alarm Number:<br>Alarm Name<br>(Alarm Description)   | Cause  | Investigative Actions  | Corrective Actions   |
|--|--|--|--|
| A.410:<br>Undervoltage<br>(Detected in the SERVOPACK main circuit power supply section.)   | <ul style="list-style-type: none"> <li>For 100-VAC SERVOPACKS:<br/>The AC power supply voltage is 49 V or less.</li> <li>For 200-VAC SERVOPACKS:<br/>The AC power supply voltage is 120 V or less.</li> <li>For 400-VAC SERVOPACKS:<br/>The AC power supply voltage is 240 V or less.</li> </ul> | Measure the power supply voltage.  | Set the power supply voltage within the specified range.   |
|  | The power supply voltage dropped during operation.   | Measure the power supply voltage.  | Increase the power supply capacity.  |
|  | Occurrence of instantaneous power interruption.  | Measure the power supply voltage.  | When the instantaneous power cut hold time (Pn509) is set, decrease the setting.   |
|  | The SERVOPACK fuse is blown out.   | —  | Replace the SERVOPACK, connect a reactor, and run the SERVOPACK.   |
|  | A SERVOPACK fault occurred.  | —  | The SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.450:<br>Main-Circuit Capacitor Overvoltage   | A SERVOPACK fault occurred.  | —  | Replace the SERVOPACK.   |
| A.510:<br>Overspeed<br>(The servomotor speed exceeds the maximum.)   | The order of phases U, V, and W in the servomotor wiring is incorrect.   | Check the motor wiring.  | Confirm that the servomotor is correctly wired.  |
|  | A reference value exceeding the overspeed detection level was input.   | Check the input value.   | Reduce the reference value or adjust the gain.   |
|  | The motor speed exceeded the maximum.  | Check the motor speed waveform.  | Reduce the speed reference input gain, adjust the servo gain, or reconsider the operating conditions.  |
|  | A SERVOPACK fault occurred.  | —  | The SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.511:<br>Overspeed of Encoder Output Pulse Rate   | The encoder output pulse frequency exceeded the limit.   | Check the encoder output pulse setting.  | Decrease the setting of the encoder output pulse (Pn212).  |
|  | The encoder output pulse output frequency exceeded the limit because the motor speed was too high.   | Check the encoder output pulse output setting and motor speed.   | Decrease the motor speed.  |
| A.520:<br>Vibration Alarm  | Abnormal vibration was detected at the motor speed.  | Check for abnormal noise from the servomotor, and check the speed and torque waveforms during operation. | Reduce the motor speed or reduce the speed loop gain (Pn100).  |
|  | The moment of inertia ratio (Pn103) value is greater than the actual value or is greatly changed.  | Check the moment of inertia ratio.   | Set the moment of inertia ratio (Pn103) to an appropriate value.   |
| A.521:<br>Autotuning Alarm<br>(Vibration was detected while executing the one-parameter tuning, EasyFFT, or tuning-less function.) | The servomotor vibrated considerably while performing tuning-less function.  | Check the motor speed waveform.  | Reduce the load so that the moment of inertia ratio falls within the allowable value, or raise the load level using the tuning-less levels setting (Fn200) or reduce the rigidity level. |
|  | The servomotor vibrated considerably during one-parameter tuning or EasyFFT.   | Check the motor speed waveform.  | Check the operation procedure of corresponding function and take a corrective action.  |

(cont'd)

| Alarm Number:<br>Alarm Name<br>(Alarm Description)  | Cause  | Investigative Actions  | Corrective Actions   |
|---|--|--|--|
| A.710:<br>A.720:<br>Overload<br>A.710: High Load<br>A.720: Low Load   | Incorrect wiring or contact fault of servomotor and encoder.   | Check the wiring.  | Confirm that the servomotor and encoder are correctly wired.   |
|   | Operation beyond the overload protection characteristics.  | Check the servomotor overload characteristics and executed run command.  | Reconsider the load conditions and operating conditions. Or, increase the motor capacity.  |
|   | Excessive load was applied during operation because the servomotor was not driven due to mechanical problems.                        | Check the executed operation reference and motor speed.  | Remove the mechanical problems.  |
|   | A SERVOPACK fault occurred.  | –  | The SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.730:<br>A.731:<br>Dynamic Brake Overload<br>(An excessive power consumption of dynamic brake was detected.)   | The servomotor rotates because of external force.  | Check the operation status.  | Take measures to ensure the servomotor will not rotate because of external force.  |
|   | The rotating energy at a DB stop exceeds the DB resistance capacity.   | Check the power consumed by DB resistance (Un00B) to see how many times the DB has been used.  | Reconsider the following: <ul style="list-style-type: none"> <li>• Reduce the motor reference speed.</li> <li>• Reduce the moment of inertia ratio.</li> <li>• Reduce the number of times of the DB stop operation.</li> </ul> |
|   | A SERVOPACK fault occurred.  | –  | The SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.740:<br>Overload of Surge Current Limit Resistor<br>(The main circuit power is turned ON/OFF too frequently.) | The inrush current limit resistor operation frequency at the main circuit power supply ON/OFF operation exceeds the allowable range. | –  | Reduce the frequency of turning the main circuit power supply ON/OFF.  |
|   | A SERVOPACK fault occurred.  | –  | The SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.7A0:<br>Heat Sink Overheated<br>(Detected when the heat sink temperature exceeds 100°C.)                      | The surrounding air temperature is too high.   | Check the surrounding air temperature using a thermostat.  | Decrease the surrounding air temperature by improving the SERVOPACK installation conditions.   |
|   | The overload alarm has been reset by turning OFF the power too many times.   | Check the alarm history display (Fn000) to see if the overload alarm was reported.   | Change the method for resetting the alarm.   |
|   | Excessive load or operation beyond the regenerative energy processing capacity.  | Check the accumulated load ratio (Un009) to see the load during operation, and the regenerative load ratio (Un00A) to see the regenerative energy processing capacity. | Reconsider the load and operating conditions.  |
|   | Incorrect SERVOPACK installation orientation or/and insufficient space around the SERVOPACK.   | Check the SERVOPACK installation conditions.   | Install the SERVOPACK correctly as specified.  |
|   | A SERVOPACK fault occurred.  | –  | The SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.7AB:<br>Built-in Fan in SERVOPACK Stopped   | The fan inside the SERVOPACK stopped.  | Check for foreign matter or debris inside the SERVOPACK.   | Remove foreign matter or debris from the SERVOPACK. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.   |

(cont'd)

| Alarm Number:<br>Alarm Name<br>(Alarm Description)  | Cause  | Investigative Actions   | Corrective Actions   |
|---|--|---|--|
| A.810:<br>Encoder Backup Error<br>(Only when an absolute encoder is connected.)<br>(Detected on the encoder side.)        | Alarm occurred when the power to the absolute encoder was initially turned ON.   | Check to see if the power was turned ON initially.  | Set up the encoder (Fn008).  |
|   | The encoder cable disconnected, and connected again.   | Check to see if the power was turned ON initially.  | Confirm the connection and set up the encoder (Fn008).   |
|   | The power from both the control power supply (+5 V) from the SERVOPACK and the battery power supply is not being supplied. | Check the encoder connector battery or the connector contact status.                                | Replace the battery or take similar measures to supply power to the encoder, and set up the encoder (Fn008).   |
|   | An absolute encoder fault occurred.  | —   | If the alarm cannot be reset by setting up the encoder again, replace the servomotor.  |
|   | A SERVOPACK fault occurred.  | —   | The SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.820:<br>Encoder Checksum Error<br>(Detected on the encoder side.)   | An encoder fault occurred.   | —   | <ul style="list-style-type: none"> <li>Absolute encoder<br/>Set up the encoder again using Fn008. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor.</li> <li>Absolute encoder that shows values for a single rotation or incremental encoder<br/>The servomotor may be faulty. Replace the servomotor.</li> </ul> |
|   | A SERVOPACK fault occurred.  | —   | The SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.830:<br>Absolute Encoder Battery Error<br>(The absolute encoder battery voltage is lower than the specified value.)     | The battery connection is incorrect.   | Check the battery connection.   | Reconnect the battery.   |
|   | The battery voltage is lower than the specified value 2.7 V.   | Measure the battery voltage.  | Replace the battery.   |
|   | A SERVOPACK fault occurred.  | —   | The SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.840:<br>Encoder Data Error<br>(Detected on the encoder side.)   | An encoder malfunctioned.  | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor.  |
|   | Malfunction of encoder because of noise interference, etc.   | —   | Correct the wiring around the encoder by separating the encoder cable from the servomotor main circuit cable or by checking the grounding and other wiring.  |
| A.850:<br>Encoder Overspeed<br>(Detected when the control power supply was turned ON.)<br>(Detected on the encoder side.) | The servomotor speed is higher than 200 min <sup>-1</sup> when the control power supply was turned ON.                     | Check the motor rotating speed (Un000) to confirm the servomotor speed when the power is turned ON. | Reduce the servomotor speed to a value less than 200 min <sup>-1</sup> , and turn ON the control power supply.   |
|   | An encoder fault occurred.   | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor.  |
|   | A SERVOPACK fault occurred.  | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.  |

(cont'd)

| Alarm Number:<br>Alarm Name<br>(Alarm Description)   | Cause   | Investigative Actions   | Corrective Actions  |
|--|---|---|---|
| A.860:<br>Encoder Overheated<br>(Only when an absolute<br>encoder is connected.)<br>(Detected on the encoder<br>side.) | The ambient operating temperature around the servomotor is too high.                                | Measure the ambient operating temperature around the servomotor.  | The ambient operating temperature must be 40°C or less.   |
|  | The motor load is greater than the rated load.  | Check the accumulated load ratio (Un009) to see the load.   | The motor load must be within the specified range.  |
|  | An encoder fault occurred.  | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor. |
|  | A SERVOPACK fault occurred.   | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.   |
| A.8A0:<br>External Encoder Error   | Setting the zero point position of external absolute encoder failed because the servomotor rotated. | Before setting the zero point position, use the fully-closed feedback pulse counter (Un00E) to confirm that the servomotor is not rotating. | The servomotor must be stopped while setting the zero point position.   |
|  | An external encoder fault occurred.   | —   | Replace the external encoder.   |
| A.8A1:<br>External Encoder Error of Module   | An external encoder fault occurred.   | —   | Replace the external encoder.   |
|  | A serial converter unit fault occurred.   | —   | Replace the serial converter unit.  |
| A.8A2:<br>External Encoder Error of Sensor (Incremental)   | An external encoder fault occurred.   | —   | Replace the external encoder.   |
| A.8A3:<br>External Encoder Error of Position (Absolute)  | An external absolute encoder fault occurred.  | —   | The external absolute encoder may be faulty. Refer to the encoder manufacturer's instruction manual for corrective actions.   |
| A.8A5:<br>External Encoder Overspeed   | The overspeed from the external encoder occurred.   | Check the maximum speed of the external encoder.  | Keep the external encoder below its maximum speed.  |
| A.8A6:<br>External Encoder Overheated  | The overheat from the external encoder occurred.  | —   | Replace the external encoder.   |
| A.b31:<br>Current Detection Error 1  | The current detection circuit for phase U is faulty.  | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.   |
| A.b32:<br>Current Detection Error 2  | The current detection circuit for phase V is faulty.  | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.   |
| A.b33:<br>Current Detection Error 3  | The detection circuit for the current is faulty.  | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.   |
|  | The servomotor main circuit cable is disconnected.  | Check for disconnection of the servomotor main circuit cable.   | Correct the servomotor wiring.  |
| A.b6A:<br>MECHATROLINK Communications ASIC Error 1   | SERVOPACK MECHATROLINK communication section fault.   | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.   |

(cont'd)

| Alarm Number:<br>Alarm Name<br>(Alarm Description)                               | Cause  | Investigative Actions   | Corrective Actions   |
|--|--|-------------------------|--|
| A.b6b:<br>MECHATROLINK<br>Communications ASIC<br>Error 2                         | MECHATROLINK data reception error occurred due to noise interference.  | –                       | Take measures against noise. Check the MECHATROLINK communications cable and FG wiring and take measures such as adding ferrite core on the MECHATROLINK communications cable. |
|  | SERVOPACK MECHATROLINK communication section fault.                    | –                       | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.bF0:<br>System Alarm 0   | A SERVOPACK fault occurred.  | –                       | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.bF1:<br>System Alarm 1   | A SERVOPACK fault occurred.  | –                       | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.bF2:<br>System Alarm 2   | A SERVOPACK fault occurred.  | –                       | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.bF3:<br>System Alarm 3   | A SERVOPACK fault occurred.  | –                       | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.bF4:<br>System Alarm 4   | A SERVOPACK fault occurred.  | –                       | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.C10:<br>Servo Overrun Detected<br>(Detected when the servomotor power is ON.)  | The order of phases U, V, and W in the servomotor wiring is incorrect. | Check the motor wiring. | Confirm that the servomotor is correctly wired.  |
|  | An encoder fault occurred.   | –                       | If the alarm still occurs after turning the power OFF and then ON again, even though the servomotor is correctly wired, the servomotor may be faulty. Replace the servomotor.  |
|  | A SERVOPACK fault occurred.  | –                       | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.C80:<br>Absolute Encoder<br>Clear Error and Multi-<br>turn Limit Setting Error | An encoder fault occurred.   | –                       | Turn the power supply OFF and then ON again. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor.  |
|  | A SERVOPACK fault occurred.  | –                       | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.  |



(cont'd)

| Alarm Number:<br>Alarm Name<br>(Alarm Description)             | Cause  | Investigative Actions                                 | Corrective Actions  |
|--|--|---|---|
| A.C90:<br>Encoder Communica-<br>tions Error                    | Contact fault of connector or incorrect wiring for encoder cable.  | Check the connector contact status for encoder cable. | Re-insert the connector and confirm that the encoder is correctly wired.  |
|  | Cable disconnection for encoder cable or short-circuit.<br>Or, incorrect cable impedance.  | Check the encoder cable.                              | Use the cable with the specified rating.  |
|  | Corrosion caused by improper temperature, humidity, or gas, short-circuit caused by intrusion of water drops or cutting oil, or connector contact fault caused by vibration. | Check the operating environment.                      | Improve the operating environmental conditions, and replace the cable. If the alarm still occurs, replace the SERVOPACK.                                    |
|  | Malfunction caused by noise interference.  | —   | Correct the wiring around the encoder by separating the encoder cable from the servomotor main circuit cable or by checking the grounding and other wiring. |
|  | A SERVOPACK fault occurred.  | —   | Connect the servomotor to another SERVOPACK, and turn ON the control power. If no alarm occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.         |
| A.C91:<br>Encoder Communica-<br>tions Position Data Er-<br>ror | Noise interference occurred on the I/O signal line because the encoder cable is bent and the sheath is damaged.  | Check the encoder cable and connector.                | Confirm that there is no problem with the cable layout.   |
|  | The encoder cable is bundled with a high-current line or near a high-current line.   | Check the cable layout for encoder cable.             | Confirm that there is no surge voltage on the cable.  |
|  | The FG potential varies because of influence from machines on the servomotor side, such as the welder.   | Check the cable layout for encoder cable.             | Properly ground the machines to separate from the encoder FG.   |
| A.C92:<br>Encoder Communica-<br>tions Timer Error              | Noise interference occurred on the I/O signal line from the encoder.   | —   | Take countermeasures against noise for the encoder wiring.  |
|  | Excessive vibration and shocks were applied to the encoder.  | Check the operating environment.                      | Reduce the machine vibration or correctly install the servomotor.   |
|  | An encoder fault occurred.   | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor.                               |
|  | A SERVOPACK fault occurred.  | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.                                 |
| A.CA0:<br>Encoder Parameter<br>Error                           | An encoder fault occurred.   | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor.                               |
|  | A SERVOPACK fault occurred.  | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.                                 |

(cont'd)

| Alarm Number:<br>Alarm Name<br>(Alarm Description)                            | Cause  | Investigative Actions                               | Corrective Actions  |
|---|--|---|---|
| A.Cb0:<br>Encoder Echoback Error  | The wiring and contact for encoder cable are incorrect.  | Check the wiring.                                   | Correct the wiring.   |
|   | Noise interference occurred due to incorrect cable specifications of encoder cable.  | –   | Use tinned annealed copper shielded twisted-pair or screened unshielded twisted-pair cable with a core of at least 0.12 mm <sup>2</sup> . |
|   | Noise interference occurred because the wiring distance for the encoder cable is too long.   | –   | The wiring distance must be 50 m max.   |
|   | The FG potential varies because of influence from machines on the servomotor side, such as the welder.   | Check the cable layout for encoder cable.           | Properly ground the machines to separate from encoder FG.   |
|   | Excessive vibration and shocks were applied to the encoder.  | Check the operating environment.                    | Reduce the machine vibration or correctly install the servomotor.   |
|   | An encoder fault occurred.   | –   | Turn the power supply OFF and then ON again. If the alarm still occurs, the servomotor may be faulty. Replace the servomotor.             |
|   | A SERVOPACK fault occurred.  | –   | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.               |
| A.CC0:<br>Multiturn Limit Disagreement  | When using a direct drive (DD) servomotor, the multiturn limit value (Pn205) is different from that of the encoder.                                | Check the value of the Pn205.                       | Correct the setting of Pn205 (0 to 65535).  |
|   | The multiturn limit value of the encoder is different from that of the SERVOPACK. Or, the multiturn limit value of the SERVOPACK has been changed. | Check the value of the Pn205 of the SERVOPACK.      | Execute Fn013 at the occurrence of alarm.   |
|   | A SERVOPACK fault occurred.  | –   | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.               |
| A.CF1:<br>Feedback Option<br>Module Communications Error<br>(Reception error) | Wiring of cable between serial converter unit and SERVOPACK is incorrect or contact is faulty.   | Check the external encoder wiring.                  | Correct the cable wiring.   |
|   | The specified cable is not used between serial converter unit and SERVOPACK.   | Confirm the external encoder wiring specifications. | Use the specified cable.  |
|   | Cable between serial converter unit and SERVOPACK is too long.   | Measure the length of this cable.                   | Use 20-m cable max.   |
|   | Sheath of cable between serial converter unit and SERVOPACK is broken.   | Check the cable for damage.                         | Replace the cable.  |
| A.CF2:<br>Feedback Option<br>Module Communications Error<br>(Timer stop)      | Noise interferes with the cable between serial converter unit and SERVOPACK.   | –   | Correct the wiring around serial converter unit, e.g., separating I/O signal line from main circuit cable or grounding.                   |
|   | A serial converter unit fault occurred.  | –   | Replace the serial converter unit.  |
|   | A SERVOPACK fault occurred.  | –   | Replace the SERVOPACK.  |

(cont'd)

| Alarm Number:<br>Alarm Name<br>(Alarm Description)  | Cause  | Investigative Actions  | Corrective Actions  |
|---|--|--|---|
| A.d00:<br>Position Error Over-<br>flow<br>(Position error exceeded<br>the value set in the<br>excessive position error<br>alarm level (Pn520).) | The servomotor U, V, and W wir-<br>ings is faulty.   | Check the servomotor main circuit<br>cable connection.                           | Confirm that there is no contact<br>fault in the motor wiring or encoder<br>wiring.   |
|   | The position reference speed is<br>too high.   | Reduce the reference speed, and<br>operate the SERVOPACK.                        | Reduce the position reference speed<br>or acceleration of position refer-<br>ence. Or, reconsider the electronic<br>gear ratio.   |
|   | The acceleration of the position<br>reference is too high.   | Reduce the reference acceleration,<br>and operate the SERVOPACK.                 | Reduce the reference acceleration<br>of the position reference using a<br>MECHATROLINK command, or<br>smooth the acceleration of the posi-<br>tion reference by selecting the posi-<br>tion reference filter (ACCFIL)<br>using a MECHATROLINK com-<br>mand. |
|   | Setting of the excessive position<br>error alarm level (Pn520) is low<br>against the operating condition.  | Check the alarm level (Pn520) to<br>see if it is set to an appropriate<br>value. | Set the Pn520 to proper value.  |
|   | A SERVOPACK fault occurred.  | –  | Turn the power supply OFF and<br>then ON again. If the alarm still<br>occurs, the SERVOPACK may be<br>faulty. Replace the SERVOPACK.  |
| A.d01:<br>Position Error Over-<br>flow Alarm at Servo<br>ON   | This alarm occurs if the servomo-<br>tor power is turned ON when the<br>position error is greater than the<br>set value of Pn526 while the ser-<br>vomotor power is OFF.   | Check the position error amount<br>(Un008) while the servomotor<br>power is OFF. | Correct the excessive position error<br>alarm level at servo ON (Pn526).  |
| A.d02:<br>Position Error Over-<br>flow Alarm by Speed<br>Limit at Servo ON  | When the position errors remain<br>in the error counter, Pn529 limits<br>the speed if the servomotor power<br>is ON. If Pn529 limits the speed<br>in such a state, this alarm occurs<br>when position references are<br>input and the number of position<br>errors exceeds the value set for<br>the excessive position error alarm<br>level (Pn520). | –  | Correct the excessive position error<br>alarm level (Pn520).<br>Or, adjust the speed limit level at<br>servo ON (Pn529).  |
| A.d10:<br>Motor-load Position<br>Error Overflow   | Motor rotation direction and<br>external encoder installation<br>direction are opposite.   | Check the and the external encoder<br>installation direction.                    | Install the external encoder in the<br>opposite direction, or change the<br>setting of the external encoder<br>usage method (Pn002.3) to reverse<br>the direction.  |
|   | Mounting of the load (e.g., stage)<br>and external encoder joint instal-<br>lation are incorrect.  | Check the external encoder<br>mechanical connection.                             | Check the mechanical joints.  |
| A.E02:<br>MECHATROLINK<br>Internal Synchroniza-<br>tion Error 1   | MECHATROLINK transmission<br>cycle fluctuated.   | –  | Remove the cause of transmission<br>cycle fluctuation at host controller.   |
|   | A SERVOPACK fault occurred.  | –  | Turn the power supply OFF and<br>then ON again. If the alarm still<br>occurs, the SERVOPACK may be<br>faulty. Replace the SERVOPACK.  |
| A.E40:<br>MECHATROLINK<br>Transmission Cycle<br>Setting Error   | Setting of MECHATROLINK<br>transmission cycle is out of speci-<br>fications range.   | Check the MECHATROLINK<br>transmission cycle setting.                            | Set the transmission cycle to the<br>proper value.  |

(cont'd)

| Alarm Number:<br>Alarm Name<br>(Alarm Description)   | Cause  | Investigative Actions  | Corrective Actions   |
|--|--|--|--|
| A.E50:<br>MECHATROLINK<br>Synchronization Error  | WDT data of host controller was not updated correctly.   | Check the WDT data updating for the host controller.                       | Update the WDT data at the host controller correctly.  |
|  | A SERVOPACK fault occurred.  | —  | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.E51:<br>MECHATROLINK<br>Synchronization<br>Failed  | WDT data of host controller was not updated correctly at the synchronization communications start, and synchronization communications could not start. | Check the WDT data updating for the host controller.                       | Update the WDT data at the host controller correctly.  |
|  | A SERVOPACK fault occurred.  | —  | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.E60:<br>MECHATROLINK<br>Communications error<br>(Reception error)                          | MECHATROLINK wiring is incorrect.  | Check the MECHATROLINK wirings.  | Correct the MECHATROLINK wiring.<br>Connect the terminator correctly.  |
|  | MECHATROLINK data reception error occurred due to noise interference.  | —  | Take measures against noise. Check the MECHATROLINK communications cable and FG wiring and take measures such as adding ferrite core on the MECHATROLINK communications cable. |
|  | A SERVOPACK fault occurred.  | —  | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.E61:<br>MECHATROLINK<br>Transmission Cycle<br>Error<br>(Synchronization<br>interval error) | MECHATROLINK transmission cycle fluctuated.  | Check the MECHATROLINK transmission cycle setting.                         | Remove the cause of transmission cycle fluctuation at host controller.   |
|  | A SERVOPACK fault occurred.  | —  | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.E71:<br>Safety Option Module<br>Detection Failure  | The connection between the SERVOPACK and the safety option module is faulty.   | Check the connection between the SERVOPACK and the safety option module.   | Correctly connect the safety option module.  |
|  | The safety option module was disconnected.   | —  | Execute Fn014 (Resetting configuration error of option module) with using the digital operator or SigmaWin+ and turn the power supply OFF and then ON again.                   |
|  | A safety option module fault occurred.   | —  | Replace the safety option module.  |
|  | A SERVOPACK fault occurred.  | —  | Replace the SERVOPACK.   |
| A.E72:<br>Feedback Option<br>Module Detection<br>Failure                                     | The connection between the SERVOPACK and the Feedback Option Module is Faulty.   | Check the connection between the SERVOPACK and the Feedback Option Module. | Correctly connect the Feedback Option Module.  |
|  | The Feedback Option Module was disconnected.   | —  | Execute resetting configuration error in option modules (Fn014) and turn the power supply OFF and then ON again.   |
|  | A Feedback Option Module fault occurred.   | —  | Replace the Feedback Option Module.  |
|  | A SERVOPACK fault occurred.  | —  | Replace the SERVOPACK.   |

(cont'd)

| Alarm Number:<br>Alarm Name<br>(Alarm Description) | Cause   | Investigative Actions  | Corrective Actions  |
|--|---|--|---|
| A.E74:<br>Unsupported Safety<br>Option Module      | A safety option module fault occurred.              | –  | Replace the safety option module.   |
|  | A unsupported safety option module was connected.   | Refer to the catalog of the connected safety option module.                                  | Connect a compatible safety option module.  |
| A.E75:<br>Unsupported Feed-<br>back Option Module  | A feedback option module fault occurred.            | –  | Replace the feedback option module.   |
|  | A unsupported feedback option module was connected. | Refer to the catalog of the connected feedback option module or the manual of the SERVOPACK. | Connect a compatible feedback option module.  |
| A.EA2:<br>DRV Alarm 2<br>(SERVOPACK WDT<br>error)  | MECHATROLINK transmission cycle fluctuated.         | Check the MECHATROLINK transmission cycle setting.   | Remove the cause of transmission cycle fluctuation at host controller.  |
|  | A SERVOPACK fault occurred.                         | –  | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK. |

(cont'd)

| Alarm Number:<br>Alarm Name<br>(Alarm Description)  | Cause   | Investigative Actions   | Corrective Actions  |
|---|---|---|---|
| A.Eb1:<br>Safety Function Signal<br>Input Timing Error  | The lag between activations of the input signals /HWBB1 and /HWBB2 for the HWBB function is ten second or more.                         | Measure the time lag between the /HWBB1 and /HWBB2 signals.   | The output signal circuits or devices for /HWBB1 and /HWBB2 or the SERVOPACK input signal circuits may be faulty. Alternatively, the input signal cables may be disconnected. Check if any of these items are faulty or have been disconnected. |
| A.Ed1:<br>Command Execution<br>Timeout  | A timeout error occurred when using an MECHATROLINK command.  | Check the motor status when the command is executed.  | Execute the SV_ON or SENS_ON command only when the motor is not running.  |
|   |   | For fully-closed loop control, check the status of the external encoder after an output is made to execute the command. | Execute the SENS_ON command only when an external encoder is connected.   |
| A.F10:<br>Main Circuit Cable<br>Open Phase<br>(With the main power supply ON, voltage was low for more than 1 second in an R, S, or T phase.)<br>(Detected when the main power supply was turned ON.) | The three-phase power supply wiring is incorrect.   | Check the power supply wiring.  | Confirm that the power supply is correctly wired.   |
|   | The three-phase power supply is unbalanced.   | Measure the voltage at each phase of the three-phase power supply.  | Balance the power supply by changing phases.  |
|   | A single-phase power is input without setting Pn00B.2 (power supply method for three-phase SERVOPACK) to 1 (single-phase power supply). | Check the power supply and the parameter setting.   | Match the parameter setting to the power supply.  |
|   | A SERVOPACK fault occurred.   | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.   |
| FL-1*2:<br>System Alarm   | SERVOPACK failure   | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.   |
| FL-2*2:<br>System Alarm   |   | —   |   |
| CPF00:<br>Digital Operator<br>Transmission Error 1  | The contact between the digital operator and the SERVOPACK is faulty.   | Check the connector contact.  | Insert securely the connector or replace the cable.   |
|   | Malfunction caused by noise interference.   | —   | Keep the digital operator or the cable away from noise sources.   |
| CPF01:<br>Digital Operator<br>Transmission Error 2  | A digital operator fault occurred.  | —   | Disconnect the digital operator and then re-connect it. If the alarm still occurs, the digital operator may be faulty. Replace the digital operator.  |
|   | A SERVOPACK fault occurred.   | —   | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.   |

\*2. These alarms are not stored in the alarm history and are displayed only in the panel display.

## 9.2 Warning Displays

The following sections describe troubleshooting in response to warning displays.

The warning name and warning meaning output are listed in order of the warning numbers in *9.2.1 List of Warnings*.

The causes of warnings and troubleshooting methods are provided in *9.2.2 Troubleshooting of Warnings*.

### 9.2.1 List of Warnings

This section provides list of warnings.

| Warning Number      | Warning Name                                    | Meaning  |
|---------------------|---|--|
| A.900* <sup>1</sup> | Position Error Overflow                         | Position error exceeded the parameter setting (Pn520×Pn51E/100).   |
| A.901* <sup>1</sup> | Position Error Overflow Alarm at Servo ON       | When the servomotor power is ON, the position error exceeded the parameter setting (Pn526×Pn528/100).  |
| A.910* <sup>1</sup> | Overload  | This warning occurs before the overload alarms (A.710 or A.720) occur. If the warning is ignored and operation continues, an overload alarm may occur.                             |
| A.911* <sup>1</sup> | Vibration                                       | Abnormal vibration at the motor speed was detected. The detection level is the same as A.520. Set whether to output an alarm or warning by the vibration detection switch (Pn310). |
| A.920* <sup>1</sup> | Regenerative Overload                           | This warning occurs before the regenerative overload alarm (A.320) occurs. If the warning is ignored and operation continues, a regenerative overload alarm may occur.             |
| A.921* <sup>1</sup> | Dynamic Brake Overload                          | This warning occurs before dynamic brake overload alarm (A.731) occurs. If the warning is ignored and operation continues, a dynamic brake overload alarm may occur.               |
| A.930* <sup>1</sup> | Absolute Encoder Battery Error                  | This warning occurs when the voltage of absolute encoder's battery is lowered.   |
| A.94A* <sup>2</sup> | Data Setting Warning 1 (Parameter Number Error) | Incorrect command parameter number was set.  |
| A.94B* <sup>2</sup> | Data Setting Warning 2 (Out of Range)           | Command input data is out of range.  |
| A.94C* <sup>2</sup> | Data Setting Warning 3 (Calculation Error)      | Calculation error was detected.  |
| A.94D* <sup>2</sup> | Data Setting Warning 4 (Parameter Size)         | Data size does not match.  |
| A.94E* <sup>2</sup> | Data Setting Warning 5 (Latch Mode Error)       | Latch mode error is detected.  |
| A.95A* <sup>2</sup> | Command Warning 1 (Unsatisfying Command)        | Command was sent although the conditions for sending a command were not satisfied.   |
| A.95B* <sup>2</sup> | Command Warning 2 (Non-supported Command)       | Unsupported command was sent.  |
| A.95D* <sup>2</sup> | Command Warning 4 (Command Interference)        | Command, especially latch command, interferes.   |
| A.95E* <sup>2</sup> | Command Warning 5 (Subcommand Disable)          | Subcommand and main command interfere.   |
| A.95F* <sup>2</sup> | Command Warning 6 (Undefined Command)           | Undefined command was sent.  |
| A.960* <sup>2</sup> | MECHATROLINK Communications Warning             | Communications error occurred during MECHATROLINK communications.  |
| A.971* <sup>3</sup> | Undervoltage                                    | This warning occurs before undervoltage alarm (A.410) occurs. If the warning is ignored and operation continues, an undervoltage alarm may occur.                                  |
| A.9A0* <sup>1</sup> | Overtravel                                      | Overtravel is detected while the servomotor power is ON.   |

\*1. Use Pn008.2 to activate or not the warning detection.

\*2. Use Pn800.1 to activate or not the warning detection.

\*3. Use Pn008.1 to activate or not the warning detection.

## 9.2.2 Troubleshooting of Warnings

Refer to the following table to identify the cause of a warning and the action to be taken. Contact your Yaskawa representative if the problem cannot be solved by the described corrective action.

| Warning Number: Warning Name (Warning Description)                 | Cause   | Investigative Actions  | Corrective Actions   |
|--|---|--|--|
| A.900:<br>Position Error Overflow                                  | The servomotor U, V, and W wirings is faulty.   | Check the servomotor main circuit cable connection.  | Confirm that there is no contact fault in the motor wiring or encoder wiring.  |
|  | The SERVOPACK gain is too low.  | Check the SERVOPACK gain.  | Increase the servo gain by using the function such as advanced autotuning.   |
|  | The acceleration of the position reference is too high.   | Reduce the reference acceleration, and operate the SERVOPACK.  | Reduce the reference acceleration of the position reference using a MECHATROLINK command, or smooth the acceleration of the position reference by selecting the position reference filter (ACCFIL) using a MECHATROLINK command. |
|  | Setting of the excessive position error alarm level (Pn520) is low against the operating condition.           | Check the alarm level (Pn520) to see if it is set to an appropriate value.                               | Set the Pn520 to proper value.   |
|  | A SERVOPACK fault occurred.   | —  | Turn the power supply OFF and then ON again. If the alarm still occurs, the SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.901:<br>Position Error Overflow Alarm at Servo ON                | When the servomotor power is ON, the position error exceeded the parameter setting (Pn526×Pn528/100).         | —  | Set an appropriate value for the excessive position error warning level at servo ON (Pn528).   |
| A.910:<br>Overload<br>(Warning before alarm A.710 or A.720 occurs) | Incorrect wiring or contact fault of servomotor and encoder.  | Check the wiring.  | Confirm that the servomotor and encoder are correctly wired.   |
|  | Operation beyond the overload protection characteristics.   | Check the motor overload characteristics and executed run command.                                       | Reconsider the load conditions and operating conditions. Or, increase the motor capacity.  |
|  | Excessive load was applied during operation because the servomotor was not driven due to mechanical problems. | Check the executed operation reference and motor speed.  | Remove the mechanical problems.  |
|  | A SERVOPACK fault occurred.   | —  | The SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.911:<br>Vibration  | Abnormal vibration was detected at the motor speed.   | Check for abnormal noise from the servomotor, and check the speed and torque waveforms during operation. | Reduce the motor speed or reduce the servo gain by using the function such as one-parameter tuning.  |
|  | The moment of inertia ratio (Pn103) value is greater than the actual value or is greatly changed.             | Check the moment of inertia ratio.   | Set the moment of inertia ratio (Pn103) to an appropriate value.   |



(cont'd)

| Warning Number: Warning Name (Warning Description)   | Cause   | Investigative Actions   | Corrective Actions   |
|--|---|---|--|
| A.920:<br>Regenerative Overload<br>(Warning before the alarm A.320 occurs)   | The power supply voltage exceeds the specified limit.   | Measure the power supply voltage.   | Set the power supply voltage within the specified range.   |
|  | Insufficient external regenerative resistance, regenerative resistor capacity, or SERVOPACK capacity.<br>Or, regenerative power has been continuously flowing back. | Check the operating condition or the capacity using the capacity selection Software SigmaJunmaSize+, etc.                                       | Change the regenerative resistance, regenerative resistor capacity, or SERVOPACK capacity. Reconsider the operating conditions using the capacity selection software SigmaJunmaSize+, etc.                                     |
|  | Regenerative power continuously flowed back because negative load was continuously applied.   | Check the load to the servomotor during operation.  | Reconsider the system including servo drives, machine, and operating conditions.   |
| A.921:<br>Dynamic Brake Overload<br>(Warning before the alarm A.731 occurs)  | The servomotor rotates because of external force.   | Check the operation status.   | Take measures to ensure the servomotor will not rotate because of external force.  |
|  | The rotating energy at a DB stop exceeds the DB resistance capacity.  | Check the power consumed by DB resistance (Un00B) to see how many times the DB has been used.   | Reconsider the following: <ul style="list-style-type: none"> <li>• Reduce the motor reference speed.</li> <li>• Reduce the moment of inertia ratio.</li> <li>• Reduce the number of times of the DB stop operation.</li> </ul> |
|  | A SERVOPACK fault occurred.   | —   | The SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.930:<br>Absolute Encoder Battery Error<br>(The absolute encoder battery voltage is lower than the specified value.)<br>* Only when an absolute encoder is connected. | The battery connection is incorrect.  | Check the battery connection.   | Reconnect the battery.   |
|  | The battery voltage is lower than the specified value 2.7 V.  | Measure the battery voltage.  | Replace the battery.   |
|  | A SERVOPACK fault occurred.   | —   | The SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.94A<br>Data Setting Warning 1<br>(Parameter Number Error)  | Disabled parameter number was used.   | Refer to 9.3 <i>Monitoring Communication Data on Occurrence of an Alarm or Warning</i> to determine which command was the cause of the warning. | Use the correct parameter number.  |
| A.94B<br>Data Setting Warning 2<br>(Out of Range)  | Attempted to send values outside the range to the command data.   | Refer to 9.3 <i>Monitoring Communication Data on Occurrence of an Alarm or Warning</i> to determine which command was the cause of the warning. | Set the value of the parameter within the allowable range.   |
| A.94C<br>Data Setting Warning 3<br>(Calculation Error)   | Calculation result of set value is incorrect.   | Refer to 9.3 <i>Monitoring Communication Data on Occurrence of an Alarm or Warning</i> to determine which command was the cause of the warning. | Set the value of the parameter within the allowable range.   |
| A.94D<br>Data Setting Warning 4<br>(Parameter Size)  | Parameter size set in command is incorrect.   | Refer to 9.3 <i>Monitoring Communication Data on Occurrence of an Alarm or Warning</i> to determine which command was the cause of the warning. | Use the correct parameter size.  |

(cont'd)

| Warning Number: Warning Name (Warning Description)          | Cause  | Investigative Actions   | Corrective Actions   |
|---|--|---|--|
| A.94E<br>Data Setting<br>Warning 5<br>(Latch mode error)    | Latch mode error is detected.  | Refer to 9.3 <i>Monitoring Communication Data on Occurrence of an Alarm or Warning</i> to determine which command was the cause of the warning. | Change the setting value of Pn850 or the LT_MOD data for the LTMOD_ON command sent by the host controller to the proper value.   |
| A.95A<br>Command<br>Warning 1<br>(Unsatisfying Command)     | Command sending condition is not satisfied.                            | Refer to 9.3 <i>Monitoring Communication Data on Occurrence of an Alarm or Warning</i> to determine which command was the cause of the warning. | Send a command after command sending condition is satisfied.   |
| A.95B<br>Command<br>Warning 2<br>(Non-supported Command)    | SERVOPACK received unsupported command.                                | Refer to 9.3 <i>Monitoring Communication Data on Occurrence of an Alarm or Warning</i> to determine which command was the cause of the warning. | Do not sent an unsupported command.  |
| A.95D<br>Command<br>Warning 4<br>(Command Interference)     | Command sending condition for latch-related commands is not satisfied. | Refer to 9.3 <i>Monitoring Communication Data on Occurrence of an Alarm or Warning</i> to determine which command was the cause of the warning. | Send a command after command sending condition is satisfied.   |
| A.95E<br>Command<br>Warning 5<br>(Subcommand Disable)       | Subcommand sending condition is not satisfied.                         | Refer to 9.3 <i>Monitoring Communication Data on Occurrence of an Alarm or Warning</i> to determine which command was the cause of the warning. | Send a command after command sending condition is satisfied.   |
| A.95F<br>Command Warn-<br>ing 6<br>(Undefined Com-<br>mand) | Undefined command was sent.  | Refer to 9.3 <i>Monitoring Communication Data on Occurrence of an Alarm or Warning</i> to determine which command was the cause of the warning. | Do not use an undefined command.   |
| A.960<br>MECHATROLINK<br>Communications<br>Warning          | MECHATROLINK wiring is incorrect.                                      | Confirm the wiring.   | Correct the MECHATROLINK wiring.<br>Or, connect a terminal to the terminal station.  |
|   | MECHATROLINK data reception error occurred due to noise interference.  | Confirm the installation conditions.  | Take measures against noise. Check the MECHATROLINK communications cable and FG wiring and take measures such as adding ferrite core on the MECHATROLINK communications cable. |
|   | A SERVOPACK fault occurred.  | —   | A fault occurred in the SERVOPACK. Replace the SERVOPACK.  |

(cont'd)

| Warning Number: Warning Name (Warning Description) | Cause  | Investigative Actions   | Corrective Actions   |
|--|--|---|--|
| A.971: Under-voltage                               | <ul style="list-style-type: none"> <li>• For 100 VAC SERVOPACKs:<br/>The AC power supply voltage is 60 V or less.</li> <li>• For 200-VAC SERVOPACKs:<br/>The AC power supply voltage is 140 V or less.</li> <li>• For 400-VAC SERVOPACKs:<br/>The AC power supply voltage is 280 V or less.</li> </ul> | Measure the power supply voltage.   | Set the power supply voltage within the specified range.   |
|  | The power supply voltage dropped during operation.   | Measure the power supply voltage.   | Increase the power supply capacity.  |
|  | Occurrence of instantaneous power interruption.  | Measure the power supply voltage.   | When the instantaneous power cut hold time (Pn509) is set, decrease the setting.   |
|  | The SERVOPACK fuse is blown out.   | —   | Replace the SERVOPACK and connect a reactor to the SERVOPACK.  |
|  | A SERVOPACK fault occurred.  | —   | The SERVOPACK may be faulty. Replace the SERVOPACK.  |
| A.9A0: Overtravel (Overtravel status is detected.) | When the servomotor power is ON, overtravel status is detected.  | Check the input signal monitor (Un005) to check the status of the overtravel signals. | <p>Refer to <i>9.4 Troubleshooting Malfunction Based on Operation and Conditions of the Servomotor</i>. Even if overtravel signals were not shown by the input signal monitor (Un005), momentary overtravel may have been detected. Take the following precautions.</p> <ul style="list-style-type: none"> <li>• Do not specify movements that would cause overtravel from the host controller.</li> <li>• Check the wiring of the overtravel signals.</li> <li>• Take countermeasures for noise.</li> </ul> |

### 9.3 Monitoring Communication Data on Occurrence of an Alarm or Warning

The command data received on occurrence of an alarm or warning, such as a data setting warning (A.94□) or a command warning (A.95□) can be monitored using the following parameters. The following is an example of the data when an alarm/warning has occurred in the normal state.

Command Data Monitor at Alarm/Warning Occurrence:Pn890 to Pn89E  
Response Data Monitor at Alarm/Warning Occurrence:Pn8A0 to Pn8AE

| Command Byte Order | Command Data Storage at Alarm/Warning Occurrence |              |
|--------------------|--|--------------|
|                    | CMD  | RSP          |
| 1                  | Pn890.1 to 0                                     | Pn8A0.1 to 0 |
| 2                  | Pn890.3 to 2                                     | Pn8A0.3 to 2 |
| 3                  | Pn890.5 to 4                                     | Pn8A0.5 to 4 |
| 4                  | Pn890.7 to 6                                     | Pn8A0.7 to 6 |
| 5 to 8             | Pn892  | Pn8A2        |
| 9 to 12            | Pn894  | Pn8A4        |
| 13 to 16           | Pn896  | Pn8A6        |
| 17 to 20           | Pn898  | Pn8A8        |
| 21 to 24           | Pn89A  | Pn8AA        |
| 25 to 28           | Pn89C  | Pn8AC        |
| 29 to 32           | Pn89E  | Pn8AE        |

Example: Pn8A0 = 87 65 43 21

- Note 1. Data is stored in little endian byte order and displayed in the hexadecimal format.  
2. For details on commands, refer to *Σ-V Series User's Manual MECHATROLINK-II Commands* (No.: S1EP S800000 54)

## 9.4 Troubleshooting Malfunction Based on Operation and Conditions of the Servomotor

Troubleshooting for the malfunctions based on the operation and conditions of the servomotor is provided in this section.

Be sure to turn OFF the servo system before troubleshooting items shown in bold lines in the table.

| Problem  | Probable Cause  | Investigative Actions   | Corrective Actions   |
|--|---|---|--|
| Servomotor Does Not Start                        | The control power supply is not ON.   | Check voltage between control power terminals.  | Correct the wiring.  |
|  | The main circuit power supply is not ON.  | Check the voltage between main circuit power terminals.                                     | Correct the wiring.  |
|  | Wiring of I/O signal connector CN1 is faulty or disconnected.                                     | Check if the connector CN1 is properly inserted and connected.                              | Correct the connector CN1 connection.  |
|  | Wiring for servomotor main circuit cable or encoder cable is disconnected.                        | Check the wiring.   | Correct the wiring.  |
|  | Overloaded  | Run under no load and check the load status.  | Reduce load or replace with larger capacity servomotor.  |
|  | Encoder type differs from parameter setting (Pn002.2).  | Check the settings for parameter Pn002.2.   | Set parameter Pn002.2 to the encoder type being used.  |
|  | Settings for the input signal selections (Pn50A, Pn50B and Pn511) is incorrect.                   | Check the settings for parameters Pn50A, Pn50B and Pn511.                                   | Correct the settings for parameter Pn50A, Pn50B and Pn511.   |
|  | SV_ON command is not sent.  | Check the command sent from the host controller.  | Send the SV_ON command.  |
|  | SENS_ON command is not sent.  | Check the command sent from the host controller.  | Send the command in the correct SERVOPACK sequence.  |
|  | The forward run prohibited (P-OT) and reverse run prohibited (N-OT) input signals are turned OFF. | Check P-OT or N-OT input signal.  | Turn P-OT or N-OT input signal ON.   |
|  | The safety input signal (/HWBB1 or /HWBB2) remains OFF.   | Check the /HWBB1 and /HWBB2 input signal.   | Set the /HWBB1 and /HWBB2 input signal to ON.<br>When not using the safety function, mount the safety function jumper connector (provided as an accessory) on the CN8. |
|  | A SERVOPACK fault occurred.   | –   | Replace the SERVOPACK.   |
| Servomotor Moves Instantaneously, and then Stops | Servomotor wiring is incorrect.   | Check the wiring.   | Correct the wiring.  |
|  | Encoder wiring is incorrect.  | Check the wiring.   | Correct the wiring.  |
| Servomotor Speed Unstable                        | Wiring connection to servomotor is defective.   | Check connections of power line (phases U, V, and W) and encoder connectors.                | Tighten any loose terminals or connectors and correct the wiring.  |
| Servomotor Rotates Without Reference Input       | A SERVOPACK fault occurred.   | –   | Replace the SERVOPACK.   |
| Dynamic Brake Does Not Operate                   | Improper Pn001.0 setting  | Check the setting for parameter Pn001.0.  | Correct the setting for parameter Pn001.0.   |
|  | DB resistor disconnected  | Check if excessive moment of inertia, motor overspeed, or DB frequently activated occurred. | Replace the SERVOPACK, and reduce the load.  |
|  | DB drive circuit fault  | –   | There is a defective component in the DB circuit. Replace the SERVOPACK.   |

(cont'd)

| Problem                                      | Probable Cause   | Investigative Actions  | Corrective Actions   |
|--|--|--|--|
| Abnormal Noise from Servomotor               | The servomotor largely vibrated during execution of tuning-less function.  | Check the motor speed waveform.  | Reduce the load so that the moment of inertia ratio becomes within the allowable value, or increase the load level or lower the tuning level for the tuning-less levels setting (Fn200). |
|  | Mounting is not secured.   | Check if there are any loose mounting screws.  | Tighten the mounting screws.   |
|  |  | Check if there is misalignment of couplings.   | Align the couplings.   |
|  |  | Check if there are unbalanced couplings.   | Balance the couplings.   |
|  | Bearings are defective.  | Check for noise and vibration around the bearings.   | Replace the servomotor.  |
|  | Vibration source at the driven machine.  | Check for any foreign matter, damage, or deformations on the machinery's movable parts.  | Contact the machine manufacturer.  |
|  | Noise interference due to incorrect I/O signal cable specifications.   | The I/O signal cable must be tinned annealed copper shielded twisted-pair or screened unshielded twisted-pair cable with a core of 0.12 mm <sup>2</sup> min. | Use the specified I/O signal cable.  |
|  | Noise interference due to length of I/O signal cable.  | Check the length of the I/O signal cable.  | The I/O signal cable length must be no more than 3 m.  |
|  | Noise interference due to incorrect cable specifications of encoder cable.   | The encoder cable must be tinned annealed copper shielded twisted-pair or screened unshielded twisted-pair cable with a core of 0.12 mm <sup>2</sup> min.    | Use the specified encoder cable.   |
|  | Noise interference due to length of encoder cable.   | Check the length of the encoder cable.   | The encoder cable must be no more than 50 m.   |
|  | Noise interference due to damaged encoder cable.   | Check if the encoder cable is bent and the sheath is damaged.  | Replace the encoder cable and correct the cable layout.  |
|  | Excessive noise to the encoder cable.  | Check if the encoder cable is bundled with a high-current line or near a high-current line.  | Correct the cable layout so that no surge is applied.  |
|  | The FG potential varies because of influence from machines on the servomotor side, such as the welder.                                     | Check if the machines are correctly grounded.  | Properly ground the machines to separate from the encoder FG.  |
|  | SERVOPACK pulse counting error due to noise interference   | Check if there is noise interference on the I/O signal line from the encoder.  | Take measures against noise in the encoder wiring.   |
| Excessive vibration and shock to the encoder | Check if vibration from the machine occurred or servomotor installation is incorrect (mounting surface accuracy, fixing, alignment, etc.). | Reduce vibration from the machine, or secure the servomotor installation.  |  |
| An encoder fault occurred.                   | —  | Replace the servomotor.  |  |

(cont'd)

| Problem  | Probable Cause  | Investigative Actions  | Corrective Actions  |
|--|---|--|---|
| Servomotor Vibrates at Frequency of Approx. 200 to 400 Hz.   | Unbalanced servo gains  | Check to see if the servo gains have been correctly adjusted.  | Execute the advanced autotuning.  |
|  | Speed loop gain value (Pn100) too high.   | Check the speed loop gain (Pn100).<br>Factory setting: $K_v = 40.0$ Hz   | Reduce the speed loop gain (Pn100).   |
|  | Position loop gain value (Pn102) too high.  | Check the position loop gain (Pn102).<br>Factory setting: $K_p = 40.0/s$   | Reduce the position loop gain (Pn102).  |
|  | Incorrect speed loop integral time constant (Pn101)                                     | Check the speed loop integral time constant (Pn101).<br>Factory setting: $T_i = 20.0$ ms   | Correct the speed loop integral time constant (Pn101).                          |
|  | Incorrect moment of inertia ratio (Pn103)   | Check the moment of inertia ratio (Pn103).   | Correct the moment of inertia ratio (Pn103).                                    |
| High Motor Speed Overshoot on Starting and Stopping  | Unbalanced servo gains  | Check to see if the servo gains have been correctly adjusted.  | Execute the advanced autotuning.  |
|  | Speed loop gain value (Pn100) too high  | Check the speed loop gain (Pn100).<br>Factory setting: $K_v = 40.0$ Hz   | Reduce the speed loop gain (Pn100).   |
|  | Position loop gain value (Pn102) too high   | Check the position loop gain (Pn102).<br>Factory setting: $K_p = 40.0/s$   | Reduce the position loop gain (Pn102).  |
|  | Incorrect speed loop integral time constant (Pn101)                                     | Check the speed loop integral time constant (Pn101).<br>Factory setting: $T_i = 20.0$ ms   | Correct the speed loop integral time constant (Pn101).                          |
|  | Incorrect moment of inertia ratio data (Pn103)  | Check the moment of inertia ratio (Pn103).   | Correct the moment of inertia ratio (Pn103).                                    |
| Absolute Encoder Position Difference Error (The position saved in the host controller when the power was turned OFF is different from the position when the power was next turned ON.) | Noise interference due to incorrect cable specifications of encoder cable.              | The encoder cable must be tinned annealed copper shielded twisted-pair or screened unshielded twisted-pair cable with a core of $0.12 \text{ mm}^2$ min. | Use the specified encoder cable.  |
|  | Noise interference due to length of encoder cable.                                      | Check the length of the encoder cable.   | The encoder cable must be no more than 50 m.                                    |
|  | Noise interference due to damaged encoder cable.  | Check if the encoder cable is bent and the sheath is damaged.  | Replace the encoder cable and correct the cable layout.                         |
|  | Excessive noise to the encoder cable.   | Check if the encoder cable is bundled with a high-current line or near a high-current line.  | Correct the cable layout so that no surge is applied.                           |
|  | FG potential varies because of influence of machines such as welders at the servomotor. | Check if the machines are correctly grounded.  | Ground machines correctly, and prevent diversion to the FG on the encoder side. |
|  | SERVOPACK pulse counting error due to noise interference                                | Check if there is noise interference on the I/O signal line from the encoder.  | Take measures against noise in the encoder wiring.                              |
|  | Excessive vibration and shock to the encoder  | Check if vibration from the machine occurred or servomotor installation is incorrect (mounting surface accuracy, fixing, alignment, etc.).               | Reduce vibration from the machine, or secure the servomotor installation.       |
|  | An encoder fault occurred.  | –  | Replace the servomotor.   |
|  | A SERVOPACK fault occurred. (The pulse count does not change.)                          | –  | Replace the SERVOPACK.  |
|  | Host controller multiturn data reading error  | Check the error detection section of the host controller.  | Correct the error detection section of the host controller.                     |
| Check if the host controller is executing data parity checks.  |   | Execute a multiturn data parity check.   |   |
| Check noise in the cable between the SERVOPACK and the host controller.  |   | Take measures against noise, and again execute a multiturn data parity check.  |   |

(cont'd)

| Problem   | Probable Cause  | Investigative Actions   | Corrective Actions   |
|---|---|---|--|
| Overtravel (OT)   | Forward or reverse run prohibited signal is input.  | Check the external power supply (+24 V) voltage for the input signal.                               | Correct the external power supply (+24 V) voltage.               |
|   |   | Check if the overtravel limit switch operates properly.   | Correct the overtravel limit switch.                             |
|   |   | Check if the overtravel limit switch is wired correctly.  | Correct the overtravel limit switch wiring.                      |
|   |   | Check the settings for parameters Pn50A and Pn50B.  | Correct the settings for parameters Pn50A and Pn50B.             |
|   | Forward or reverse run prohibited signal malfunctioning.  | Check the fluctuation of the external power supply (+24 V) voltage for the input signal.            | Stabilize the external power supply (+24 V) voltage.             |
|   |   | Check if the overtravel limit switch operates correctly.  | Correct the overtravel limit switch.                             |
|   |   | Check if the overtravel limit switch wiring is correct. (check for damaged cables or loose screws.) | Correct the overtravel limit switch wiring.                      |
|   | Incorrect forward or reverse run prohibited signal (P-OT/N-OT) allocation (parameters Pn50A.3, Pn50B.0) | Check if the P-OT signal is allocated in Pn50A.3.   | If another signal is allocated in Pn50A.3, allocate P-OT.        |
|   |   | Check if the N-OT signal is allocated in Pn50B.0.   | If another signal is allocated in Pn50B.0, allocate N-OT.        |
|   | Incorrect servomotor stop method selection  | Check the settings for parameters Pn001.0 and Pn001.1 when the servomotor power is OFF.             | Select a servomotor stop method other than "coast to stop."      |
| Check the settings for parameters Pn001.0 and Pn001.1 when in torque control. |   | Select a servomotor stop method other than "coast to stop."   |  |
| Improper Stop Position by Overtravel (OT) Signal                              | Improper limit switch position and dog length   | —   | Install the limit switch at the appropriate position.            |
|   | The overtravel limit switch position is too short for the coasting distance.                            | —   | Install the overtravel limit switch at the appropriate position. |



(cont'd)

| Problem                           | Probable Cause  | Investigative Actions  | Corrective Actions   |
|-----------------------------------|---|--|--|
| Position Error<br>(Without Alarm) | Noise interference due to incorrect encoder cable specifications                                      | The encoder cable must be tinned annealed copper shielded twisted-pair or screened unshielded twisted-pair cable with a core of 0.12 mm <sup>2</sup> min.    | Use the specified encoder cable.   |
|                                   | Noise interference due to length of encoder cable.  | Check the length of the encoder cable.   | The encoder cable must be no more than 50 m.   |
|                                   | Noise influence due to damaged encoder cable.   | Check if the encoder cable is bent and the sheath is damaged.  | Replace the encoder cable and modify the cable layout.                               |
|                                   | Excessive noise to encoder cable.   | Check if the encoder cable is bundled with a high-current line or near a high-current line.  | Change the cable layout so that no surge is applied.                                 |
|                                   | The FG potential varies because of influence from machines on the servomotor side such as the welder. | Check if the machines are correctly grounded.  | Properly ground the machines encoder FG.   |
|                                   | SERVOPACK pulse count error due to noise  | Check if the I/O signal line from the encoder is influenced by noise.  | Take measures against noise in the encoder wiring.                                   |
|                                   | Excessive vibration and shock to the encoder  | Check if vibration from the machine occurred or servomotor installation is incorrect (mounting surface accuracy, fixing, alignment, etc.).                   | Reduce the machine vibration or mount the servomotor securely.                       |
|                                   | Unsecured coupling between machine and servomotor   | Check if a position error occurs at the coupling between machine and servomotor.   | Secure the coupling between the machine and servomotor.                              |
|                                   | Noise interference due to improper I/O signal cable specifications                                    | The I/O signal cable must be tinned annealed copper shielded twisted-pair or screened unshielded twisted-pair cable with a core of 0.12 mm <sup>2</sup> min. | Use input signal cable with the specified specifications.                            |
|                                   | Noise interference due to length of I/O signal cable  | Check the I/O signal cable length.   | The I/O signal cable length must be no more than 3 m.                                |
|                                   | An encoder fault occurred. (The pulse count does not change.)   | –  | Replace the servomotor.  |
| A SERVOPACK fault occurred.       | –   | Replace the SERVOPACK.   |  |
| Servomotor Overheated             | Ambient operating temperature too high  | Measure the servomotor ambient operating temperature.  | Reduce the ambient operating temperature to 40°C or less.                            |
|                                   | Servomotor surface dirty  | Visually check the surface.  | Clean dust and oil from the surface.   |
|                                   | Servomotor overloaded   | Check the load status with monitor.  | If overloaded, reduce load or replace with larger capacity SERVOPACK and servomotor. |